LABORATORY REPORT



Case Number: AS-10-3341-F-V1

3 Baron-Hay Court South Perth, WA 6151 • Tel: (08) 9368 3351 • Fax: (08) 9474 1881 444 Albany Highway, Albany, WA 6330 • Tel: (08) 9892 8444 • Fax: (08) 9892 8564

Final Report Page 1 of 4

cc.

Date: 16-NOV-2010 Your Ref: Not Supplied

Enquiries: Dr Nicky Buller(Bacteriology Perth)

To: Gavin Partridge

Challenger TAFE

1 Fleet St Fremantle WA

Owner:

Project: Animal sample testing - non disease investigation

Species: Water - Water

Samples Received: 18 water samples

Date Collected: Not Supplied Date Received: 27-OCT-2010 Submission Number: 71347

Methods

Two experiments were conducted to determine the concentration of chlorine dioxide (CleanOxide) required to kill the fish pathogen, *Streptococcus iniae*. The Australian Centre for Applied Aquaculture Research (ACAAR) prepared a stock solution of chlorine dioxide (CleanOxide) for each experiment and provided it to the Animal Health Laboratories. A 7500 ppm stock solution was prepared according to the manufacturers directions and diluted to achieve a working solution of 2000 ppb and 12000 ppb for trial 1 and 2, respectively. The concentration of this stock solution was confirmed spectrophotometrically immediately prior to use in the disinfection trials using a Hach DR 2400 with Method #10126.


Disinfection trials were conducted at the The Animal Health Laboratories. Laboratory staff prepared a pure culture of the pathogen S.iniae in nutrient broth at a concentration of $\sim 2 \times 10^5$ CFU/mL. Prior to disinfection trials, bacteria was concentrated then resuspended in isotonic saline to reduce the organic load within the vials; ensuring that CleanOxide was targeted at bacteria, rather than to oxidising the nutrients within the broth. The effectiveness of nine concentrations of CleanOxide against S.iniae were tested in duplicate at concentrations ranging from 0 to 347 ppb in Trial 1 and 0 to 3100 ppb in Trial 2. After exposure to the desired concentration for 60 minutes, CleanOxide was neutralised with sodium thiosulphate and the remaining bacteria enumerated.



ANIMAL HEALTH LABORATORIES



Case Number: AS-10-3341-F-V1



Final Report

3 Baron-Hay Court South Perth, WA 6151 • Tel: (08) 9368 3351 • Fax: (08) 9474 1881 444 Albany Highway, Albany, WA 6330 • Tel: (08) 9892 8444 • Fax: (08) 9892 8564

Page 2 of 4

Results

Bacterial counts for Trial 1 are presented in Table 1 and Figure 1 and for Trial 2 in Table 2 and Figure 2. There were no significant reductions in S. iniae at CleanOxide concentrations up to 347 ppb in Trial 1. In Trial 2, kill rates of >97% were obtained at a CleanOxide concentration >1127 ppb. At a concentration >1459 ppb a kill rate >99.99% was achieved. These results demonstrate that S. iniae is more difficult to kill than, V. mimicus which had was reduced by 64% and by >99.9% at CleanOxide concentrations of 332 and 369 ppb.

Table 1.

Spec No.	Spec ID	Spec Description	Total count
1	1	0 ppb ClO2	1 200 000 cfu/mL
2	2	0 ppb ClO2	840 000 cfu/mL
3	3	44 ppb ClO2	1 100 000 cfu/mL
4	4	44 ppb ClO2	1 210 000 cfu/mL
5	5	85 ppb ClO2	920 000 cfu/mL
6	6	85 ppb ClO2	1 200 000 cfu/mL
7	7	124 ppb ClO2	1 165 000 cfu/mL
8	8	124 ppb ClO2	910 000 cfu/mL
9	9	161 ppb ClO2	1 005 000 cfu/mL
10	10	161 ppb ClO2	905 000 cfu/mL
11	11	196 ppb ClO2	865 000 cfu/mL
12	12	196 ppb ClO2	1 200 000 cfu/mL
13	13	229 ppb ClO2	1 295 000 cfu/mL
14	14	229 ppb ClO2	870 000 cfu/mL
15	15	320 ppb ClO2	1 085 000 cfu/mL
16	16	320 ppb ClO2	1 120 000 cfu/mL
17	17	347 ppb ClO2	860 000 cfu/mL
18	18	347 ppb ClO2	985 000 cfu/mL



LABORATORY REPORT



Case Number: AS-10-3341-F-V1



3 Baron-Hay Court South Perth, WA 6151 • Tel: (08) 9368 3351 • Fax: (08) 9474 1881 444 Albany Highway, Albany, WA 6330 • Tel: (08) 9892 8444 • Fax: (08) 9892 8564

Final Report Page 3 of 4






Figure 1

Table 2.

Spec No.	Spec ID	Spec Description	Total count
1	1	0 ppb ClO2	215 000 cfu/mL
2	2	0 ppb ClO2	150 000 cfu/mL
3	3	326 ppb ClO2	99 000 cfu/mL
4	4	326 ppb ClO2	78 000 cfu/mL
5	5	361 ppb ClO2	62 000 cfu/mL
6	6	361 ppb ClO2	64 500 cfu/mL
7	7	477 ppb ClO2	42 000 cfu/mL
8	8	477 ppb ClO2	23 000 cfu/mL
9	9	590 ppb ClO2	25 500 cfu/mL
10	10	590 ppb ClO2	19 500 cfu/mL
11	11	775 ppb ClO2	23 000 cfu/mL
12	12	775 ppb ClO2	32 500 cfu/mL
13	13	1127 ppb ClO2	6000 cfu/mL
14	14	1127 ppb ClO2	5000 cfu/mL
15	15	1459 ppb ClO2	30 cfu/mL
16	16	1459 ppb ClO2	10 cfu/mL
17	17	3100 ppb ClO2	10 cfu/mL
18	18	3100 ppb ClO2	30 cfu/mL



LABORATORY REPORT



Case Number: AS-10-3341-F-V1



3 Baron-Hay Court South Perth, WA 6151 • Tel: (08) 9368 3351 • Fax: (08) 9474 1881 444 Albany Highway, Albany, WA 6330 • Tel: (08) 9892 8444 • Fax: (08) 9892 8564

Final Report Page 4 of 4




Figure 2

Yours faithfully

Dr Nicky Buller SENIOR MICROBIOLOGIST

